


START

1


Resistor - Weerstand - Résistance - Widerstand - Resistencia - Motstand - Vastus - Resistenze



(Red, Red, Red) - (Rood, Rood, Rood) (Rouge, Rouge, Rouge) - (Rot, Rot, Rot) - (Röd, Röd, Röd) - (Punainen, Punainen, Punainen) - (Rojo, Rojo, Rojo) - (Encarnado, Encarnado, Encarnado) - (Rosso, Rosso, Rosso)

2


LDR



◇ LDR : LDR04

3


Diode



◇ D1 : 1N4148
◇ D2 : 1N4148

4


IC socket



◇ IC1 : 14p

5


Transistor



◇ T1 : BC547

6


Capacitor



◇ C1, C2 : 100nF (104)

7


Electrolytic capacitor



◇ C3 : 1µF
◇ C4 : 100µF

8


Trimmer



◇ RV1 : 47K (50K)
◇ RV2 : 470K (500K)
◇ RV3 : 47K (50K)
◇ RV4 : 470K (500K)

9


IC



◇ IC1 : CD4093

10


Piezo



⊕ = Red -Rood - Rouge - Rot - Röd - Punainen
Rojo - Encarnado - Rosso




11



12

Sound adjustment - Geluid afregelen - Réglage du son - Klang Feinabstimmung - Reglaje del sonido - Regolazione del suono - Äänen säätö - Ljud inställning - Ajuste de som.

1




◇ RV1: MIN ⇒ Turn all trimmers at minimum.
◇ RV2: MIN ⇒ Draai alle trimmers op minimum.
◇ RV3: MIN ⇒ Tournez tous les potentiomètres trim à min.
◇ RV4: MIN ⇒ Reglen Sie alle Pot.meters an min.
◇ RV4: MIN ⇒ Girar los trimmers al mínimo.
◇ RV4: MIN ⇒ Girare i trimmer al minimo.
◇ RV4: MIN ⇒ Säädä trimmerit minimiasentoon.
◇ RV4: MIN ⇒ Justera trimmpotentiometern till minimum.

2

⇒ Insert a 9V battery.
⇒ Monteer een 9V bat.
⇒ Montez une batt. de 9V.
⇒ Monteren Sie ein 9V bat.
⇒ Insertar una pila de 9V.
⇒ Inserire una batteria da 9V.
⇒ Asenna 9V paristo.
⇒ Anslut ett 9 Volts batteri.
⇒ Colocar uma pilha de 9V



3



⇒ Adjust the trimmers in the indicated order.
⇒ De trimmers afregelen in de aangegeven volgorde.
⇒ Effectuez les réglages dans l'ordre indiqué.
⇒ Halten Sie sich bei den Feinabstimmungen an die angegebene Reihenfolge.
⇒ Ajustar los trimmers en el orden indicado.
⇒ Regolare i trimmer nell'ordine indicato.
⇒ Säädä trimmerit oikeassa järjestyksessä.
⇒ Justera trimmpotentiometern i indikerad ordning.
⇒ Ajustar os potenciometros na ordem indicada.