


USB 300-second Sound Module Quick Start Guide

SKU: UXM300

Here is a quick overview of the UXM300

- Please note that this unit is fairly quiet
- Record and re-record sound
- Total recording time: up to 300 seconds of high sound quality
- Can be used with MP3 or .wav files (please note that MP3 files seem to playback better)
- Shows up just like a USB flash drive when plugged in
- To program, just drag the sound file you wish onto the device from your computer

Step 1: Plug the sound module into your computer using the supplied USB cable. Once the unit is plugged in, it should appear as a USB device (see image below)



Step 2: Next you will need to click on the device and remove any test files that are on the unit.

Step 3: Once the test file has been removed, drag and drop the file you wish to use on the device.

Step 4: Once your new file is on the device you will need to disconnect the device from your computer by unplugging the USB cable.

Step 5: Add 3xAAA to the unit and turn the device on. Once the button is pressed, your new sound should play.